



# RINSE AID

## For Automatic Dish Machines

This concentrated rinse additive causes water to “sheet off” dishes, glassware, etc. in machine dishwashing operations. Provides rapid drying to eliminate water spotting. Performs under a wide range of water hardness to prevent deposition of solids. Can be used with all types of dispensing equipment. This product is a high quality rinse additive. It helps reduce surface tension, providing clean, spot-free dishware. It works well in most water conditions, eliminating the concern of water spots remaining on the dishware.

### ■ PHYSICAL PROPERTIES

APPEARANCE: Cloudy Blue Liquid

SPECIFIC GRAVITY: 1.023

ODOR: Characteristic

pH (Conc.): 10 to 12

FLASH POINT: N/A (WATER-BASED LIQUID)

### ■ PACKAGING

Rinse Aid is available in 4x1 gallon cases and 5 gallon pails.

### ■ ADDITIONAL INFORMATION

If you need additional information, please contact our corporate office at 816-471-3602. For a Material Safety Data Sheet go to [www.chemicaluniverse.com](http://www.chemicaluniverse.com).

### ■ DIRECTIONS

1. Pre-flush and/or scrape dishes before washing.
2. Rack dishes properly.
3. Place dishes in machine.
4. Wash using a recommended dishwashing detergent.
5. Use this product in the rinse cycle.
6. Allow dishes to air dry.

Note: Be sure rinse injector is working properly.

### ■ SAFE STORAGE & HANDLING

Caution: This product is intended for Industrial and institutional use. Although this is a mild cleaning agent, It can cause irritation to eyes and skin. Avoid contact by wearing protective devices such as safety glasses and rubber gloves. Always read the Material Safety Data Sheet for additional precautions before using this product.

#### FIRST AID

**Ingestion:** Do not induce vomiting. If patient is conscious and can swallow, administer milk or water.

**Skin:** Flood skin with water for 15 minutes.

**Eyes:** Flood with lukewarm water poured from a large glass held 2 to 3 inches from eyes. Remove contacts. Have patient blink as much as possible while flooding the eyes. Continue treatment for 15 minutes.

Storage: Do not Freeze. Store in dry area.