



103

HEAVY DUTY ALL-PURPOSE CLEANER



PHYSICAL PROPERTIES

Appearance: Orange Liquid

Specific Gravity: 0.99

Odor: Citrus

Ph (Conc.): 5-6

Flash Point: >212°F (100°C)

PACKAGING

4X1 gal

[VIEW DEMO VIDEO](#)

ABOUT THIS PRODUCT

LockNLoad 103 HD Citrus All-Purpose Cleaner is an all natural solvent using the cleaning ability of d-Limonene from orange peel extracts. The powerful solvent will remove heavy grease and oils, tar and asphalt.

LockNLoad 103 HD Citrus All-Purpose Cleaner can also be used to remove residue left from adhesives.

DIRECTIONS

Insert container into the LockNLoad Dilution Station. Lock the container into place by sliding the blue lock to the left. This locks in the container and connects it to the Dilution Station. The Dilution Station is set to properly dilute the concentrate with water.

To fill small containers by using the short hose on the right side of the Dilution Station. Insert the short tube into your container and push up on the container to activate or push up on the grey button on the face of the Dilution Station. To fill a large container, use the long hose on the left side of the Dilution Station. Place the hose end in the container and push the button on the black gas pump style handle. (hose does not automatically shut off when container is full).

LockNLoad products are designed to be used with the LockNLoad Dispensing Station. The product should be loaded into the Dispensing Station and locked into place. Using the Dispensing Station will ensure that the concentrate is diluted correctly at 64:1. One gallon of LockNLoad Concentrate makes 64 gallons of ready to use product.

The grey dilution lock in the opening of the container should never be removed. If the dilution lock has been removed, the contents of the container and the container should be properly disposed of.

PRECAUTIONARY STATEMENTS

Prevention: Wear eye protection/face protection. Wash hands and exposed skin thoroughly after handling. Wear protective gloves. **Response:** Call a POISON CENTER/doctor/medical professional if you feel unwell. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/doctor/medical professional. **IF ON SKIN:** Wash with plenty of water for at least 15 minutes. Specific treatment (see section 4 on the Safety Data Sheet). If skin irritation occurs: Get medical advice/attention. Take off contaminated clothing and wash it before reuse.



SCAN FOR SDS