



107

FLOOR FINISH RESTORER



PHYSICAL PROPERTIES

Appearance: Red Liquid
Specific Gravity: 1.0
Odor: Characteristic
Ph (Conc.): 8-9
Flash Point: >212°F (100°C)

PACKAGING

4X1 gal

[VIEW DEMO VIDEO](#)



SCAN FOR SDS

ABOUT THIS PRODUCT

LockNLoad 107 Floor Finish Restorer should be used as a regular part of propane and other high speed floor maintenance programs to greatly reduce labor and provide outstanding results.

Mop and Burnish Method: Damp mop floor with solution, evenly applying a thin coat. Let floor dry thoroughly, burnish floor with a high speed floor machine and the proper burnish pad.

Automatic Scrubber Method: Scrub the floor, picking up solution and use a detail mop as necessary. Let the floor dry thoroughly and burnish with a propane or other high speed floor equipment.

DIRECTIONS

Always dust mop the floor before using LockNLoad 107.

Insert container into the LockNLoad Dilution Station. Lock the container into place by sliding the blue lock to the left. This locks in the container and connects it to the Dilution Station. The Dilution Station is set to properly dilute the concentrate with water.

To fill small containers by using the short hose on the right side of the Dilution Station. Insert the short tube into your container and push up on the container to activate or push up on the grey button on the face of the Dilution Station. To fill a large container, use the long hose on the left side of the Dilution Station. Place the hose end in the container and push the button on the black gas pump style handle. (hose does not automatically shut of when container is full).

LockNLoad products are designed to be used with the LockNLoad Dispensing Station. The product should be loaded into the Dispensing Station and locked into place. Using the Dispensing Station will ensure that the concentrate is diluted correctly at 64:1. One gallon of LockNLoad Concentrate makes 64 gallons of ready to use product.

The grey dilution lock in the opening of the container should never be removed. If the dilution lock has been removed, the contents of the container and the container should be properly disposed of.

PRECAUTIONARY STATEMENTS

Prevention: Wash hands and exposed skin thoroughly after handling. Wear eye protection/face protection. **Response:** If skin irritation occurs: Get medical advice/attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. If eye irritation persists: Get medical advice/attention.